U.S. DEPARTMENT OF HOMELAND SECURITY FEDERAL EMERGENCY MANAGEMENT AGENCY National Flood Insurance Program

ELEVATION CERTIFICATE

Important: Read the instructions on pages 1-9.

OMB No. 1660-0008

Expiration Date: July 31, 2015

SEC	TION A – PROPERTY INFORMATION	FOR INSURANCE COMPANY USE
A1. Building Owner's Name GARY R. & SALLIE A. BEAUMO	NT	Policy Number:
A2. Building Street Address (including Apt., Unit, Suite, and/or 1164 WINTERBERRY DRIVE	Bldg. No.) or P.O. Route and Box No.	Company NAIC Number:
City MARCO ISLAND	State FL ZIP Code 34145	-
A3. Property Description (Lot and Block Numbers, Tax Parcel LOT 9, BLOCK 218, MARCO BEACH UNIT SEVEN	Number, Legal Description, etc.)	
 A4. Building Use (e.g., Residential, Non-Residential, Addition, A5. Latitude/Longitude: Lat. 25°55' 21.43"N Long. 81°43' 10 A6. Attach at least 2 photographs of the building if the Certification A7. Building Diagram Number 1-B A8. For a building with a crawlspace or enclosure(s): a) Square footage of crawlspace or enclosure(s) b) Number of permanent flood openings in the crawlspace or enclosure(s) within 1.0 foot above adjacent grade c) Total net area of flood openings in A8.b d) Engineered flood openings?	A9. For a building M/A sq ft a) Square by Number within 1 N/A sq in c) Total ne	rizontal Datum: NAD 1927 NAD 1983 ng with an attached garage: footage of attached garage 456 sq ft of permanent flood openings in the attached garage 0 foot above adjacent grade 3 et area of flood openings in A9.b 600 sq in pered flood openings? Yes No
SECTION B – FLOOD	INSURANCE RATE MAP (FIRM) IN	IFORMATION
B1. NFIP Community Name & Community Number CITY OF MARCO ISLAND 120426	B2. County Name COLLIER	B3. State FLORIDA
B4. Map/Panel Number B5. Suffix B6. FIRM Index 5/16/2012	Date B7. FIRM Panel Effective/Revised Date 5/16/2012	B8. Flood Zone(s) AE B9. Base Flood Elevation(s) (Zone AO, use base flood depth) 8.0'
☐ FIS Profile ☐ FIRM ☐ Community De 311. Indicate elevation datum used for BFE in Item B9: ☐ NG 112. Is the building located in a Coastal Barrier Resources Syst Designation Date:	VD 1929 ⊠ NAVD 1988 □	Other/Source: Area (OPA)?
SECTION C – BUILDING	ELEVATION INFORMATION (SUR	VEY REQUIRED)
C1. Building elevations are based on: *A new Elevation Certificate will be required when construct C2. Elevations – Zones A1–A30, AE, AH, A (with BFE), VE, V1- below according to the building diagram specified in Item A: Benchmark Utilized: SITE Indicate elevation datum used for the elevations in items a) Datum used for building elevations must be the same as the a) Top of bottom floor (including basement, crawlspace, or e) b) Top of the next higher floor	ion of the building is complete. -V30, V (with BFE), AR, AR/A, AR/AE, AF 7. In Puerto Rico only, enter meters. Vertical Datum: NAVD 88 through h) below. □ NGVD 1929 ☑ NA at used for the BFE.	R/A1-A30, AR/AH, AR/AO. Complete Items C2.a-h
c) Bottom of the lowest horizontal structural member (V Zond) Attached garage (top of slab)		
 e) Lowest elevation of machinery or equipment servicing the (Describe type of equipment and location in Comments) f) Lowest adjacent (finished) grade next to building (LAG) g) Highest adjacent (finished) grade next to building (HAG) h) Lowest adjacent grade at lowest elevation of deck or stai 	7.1 9.0 6.8 7.0	☐ feet ☐ meters
(Describe type of equipment and location in Comments) f) Lowest adjacent (finished) grade next to building (LAG) g) Highest adjacent (finished) grade next to building (HAG) h) Lowest adjacent grade at lowest elevation of deck or stai	7.1 9.0 6.8 7.0	☐ feet
(Describe type of equipment and location in Comments) f) Lowest adjacent (finished) grade next to building (LAG) g) Highest adjacent (finished) grade next to building (HAG) h) Lowest adjacent grade at lowest elevation of deck or stai SECTION D – SURVEYO This certification is to be signed and sealed by a land surveyor, information. I certify that the information on this Certificate represent understand that any false statement may be punishable by fin Check here if comments are provided on back of form. Check here if attachments. Certifier's Name DAVID C. HOLMAN (14.0097)	T.1 9.0 6.8 7.0 rs, including structural support N./A DR, ENGINEER, OR ARCHITECT C engineer, or architect authorized by law tesents my best efforts to interpret the data e or imprisonment under 18 U.S. Code, S Were latitude and longitude in Section I licensed land surveyor? Yes License Number PSM	feet meters feet
(Describe type of equipment and location in Comments) f) Lowest adjacent (finished) grade next to building (LAG) g) Highest adjacent (finished) grade next to building (HAG) h) Lowest adjacent grade at lowest elevation of deck or stai SECTION D – SURVEYO This certification is to be signed and sealed by a land surveyor, information. I certify that the information on this Certificate represent understand that any false statement may be punishable by fin Check here if comments are provided on back of form. Check here if attachments. Certifier's Name DAVID C. HOLMAN (14.0097)	rs, including structural support N./A DR, ENGINEER, OR ARCHITECT C engineer, or architect authorized by law to the sents my best efforts to interpret the data to or imprisonment under 18 U.S. Code, S Were latitude and longitude in Section of licensed land surveyor?	feet meters feet feet meters feet feet

ELEVATION CERTIFICATE, pa	ge 2			
IMPORTANT: In these spaces, co	opy the corresponding information from S	Section A.	FOF	R INSURANCE COMPANY USE
Building Street Address (including Apt., 1164 WINTERBERRY DRIVE	, Unit, Suite, and/or Bldg. No.) or P.O. Route and I	Box No.	Polic	cy Number:
City MARCO ISLAND	State FL Z	IP Code 341	45 Com	npany NAIC Number:
SECTION	D – SURVEYOR, ENGINEER, OR ARCHIT	ECT CERTII	FICATION (CONT	INUED)
Copy both sides of this Elevation Certif	icate for (1) community official, (2) insurance ager	nt/company, a	nd (3) building owne	r.
Comments A9b= SMART VENT MOD	EL # 1540-520 CERTIFIED FOR 200 SQ INCH E	ACH, C2e= A	/C PAD	
Signature	Date 1	/27/15		
SECTION E – BUILDING ELEV	VATION INFORMATION (SURVEY NOT RE	QUIRED) F	OR ZONE AO AN	D ZONE A (WITHOUT BFE)
	·	•		· ·
For Zones AO and A (without BFE), co and C. For Items E1–E4, use natural of	omplete Items E1–E5. If the Certificate is intended prade, if available. Check the measurement used.	to support a L n Puerto Rico	OMA or LOMR-F re only, enter meters.	quest, complete Sections A, B,
E1. Provide elevation information for	the following and check the appropriate boxes to		•	ve or below the highest adjacent
grade (HAG) and the lowest adja a) Top of bottom floor (including	icent grade (LAG). basement, crawlspace, or enclosure) is	fe	et 🗌 meters 🗌 ab	ove or Delow the HAG.
	basement, crawlspace, or enclosure) is permanent flood openings provided in Section A Ite			ove or below the LAG.
			e or D below the H	
E3. Attached garage (top of slab) is	feet meters above d/or equipment servicing the building is			or D below the HAG
	number is available, is the top of the bottom floor ϵ			
ordinance? ☐ Yes ☐ No ☐	Unknown. The local official must certify this info	rmation in Sec	ction G.	
SECTION	F – PROPERTY OWNER (OR OWNER'S R	EPRESENT	ATIVE) CERTIFIC	CATION
	zed representative who completes Sections A, B, a nents in Sections A, B, and E are correct to the be			-issued or community-issued BFE)
Property Owner's or Owner's Authorize	d Representative's Name			
Address	City		State	ZIP Code
Signature	Date		Telephone	
Comments				
				☐ Check here if attachments.
	CECTION C. COMMUNITY INFORM	IATION (OD	TIONAL	
The local official who is authorized by law	SECTION G – COMMUNITY INFORM or ordinance to administer the community's floodpla		<u> </u>	mplete Sections A, B, C (or E), and G
·	applicable item(s) and sign below. Check the measure			•
	vas taken from other documentation that has been elevation information. (Indicate the source and da			
G2. A community official complete	d Section E for a building located in Zone A (witho	ut a FEMA-iss	sued or community-is	ssued BFE) or Zone AO.
G3. The following information (Item	ns G4-G10) is provided for community floodplain r	management _l	purposes.	
G4. Permit Number	G5. Date Permit Issued	G6. Date C	ertificate Of Complia	nce/Occupancy Issued
G7. This permit has been issued for:	☐ New Construction ☐ Substantial Imp	rovement		
G8. Elevation of as-built lowest floor (in	cluding basement) of the building:	☐ feet	☐ meters Da	utum
G9. BFE or (in Zone AO) depth of flood		☐ feet	_	atum
G10. Community's design flood elevation	1:	∐ feet	∐ meters Da	tum
Local Official's Name	Title			
Community Name	Tele	phone		
Signature	Date	e		
Comments				☐ Check here if attachments.

FEMA Form 086-0-33 (7/12) Replaces all previous editions.

Building Photographs See Instructions for Item A6.

IMPORTANT: In these spaces, copy the correspond	ding information fro	om Section A.	FOR INSURANCE COMPANY USE
Building Street Address (including Apt., Unit, Suite, and/or Bldg. No.) or P.O. Route and Box No. 1164 WINTERBERRY DRIVE		Policy Number:	
City MARCO ISLAND	State FL	ZIP Code 34145	Company NAIC Number:

If using the Elevation Certificate to obtain NFIP flood insurance, affix at least 2 building photographs below according to the instructions for Item A6. Identify all photographs with date taken; "Front View" and "Rear View"; and, if required, "Right Side View" and "Left Side View." When applicable, photographs must show the foundation with representative examples of the flood openings or vents, as indicated in Section A8. If submitting more photographs than will fit on this page, use the Continuation Page.



FRONT VIEW 1/27/15




REAR VIEW 1/27/15

Building Photographs Continuation Page

		•	
IMPORTANT: In these spaces, copy the corresponding information from Section A.		FOR INSURANCE COMPANY USE	
Building Street Address (including Apt., Unit, Suite, and/or Bldg. No.) or P.O. Route and Box No. 1164 WINTERBERRY DRIVE		Policy Number:	
City MARCO ISLAND	State FL	ZIP Code 34145	Company NAIC Number:

If submitting more photographs than will fit on the preceding page, affix the additional photographs below. Identify all photographs with: date taken; "Front View" and "Rear View"; and, if required, "Right Side View" and "Left Side View." When applicable, photographs must show the foundation with representative examples of the flood openings or vents, as indicated in Section A8.



LEFT SIDE VIEW 1/27/15



RIGHT SIDE VIEW 1/27/15



ICC-ES Evaluation Report

ESR-2074

Reissued February 2015 Revised May 2016

This report is subject to renewal February 2017.

www.icc-es.org | (800) 423-6587 | (562) 699-0543

A Subsidiary of the International Code Council®

DIVISION: 08 00 00-OPENINGS

Section: 08 95 43-Vents/Foundation Flood Vents

REPORT HOLDER:

SMARTVENT PRODUCTS, INC. 430 ANDBRO DRIVE, UNIT 1 PITMAN, NEW JERSEY 08071 (877) 441-8368

www.smartvent.com info@smartvent.com

EVALUATION SUBJECT:

SMART VENT® AUTOMATIC FOUNDATION FLOOD VENTS: MODELS #1540-520; #1540-521; #1540-510; #1540-511; #1540-570; #1540-574; #1540-524; #1540-514

1.0 EVALUATION SCOPE

Compliance with the following codes:

- 2015, 2012, 2009 and 2006 International Building Code[®] (IBC)
- 2015, 2012, 2009 and 2006 International Residential Code[®] (IRC)
- 2013 Abu Dhabi International Building Code (ADIBC)[†]

[†]The ADIBC is based on the 2009 IBC. 2009 IBC code sections referenced in this report are the same sections in the ADIBC.

Properties evaluated:

- Physical operation
- Water flow

2.0 USES

The Smart Vent[®] units are engineered mechanically operated flood vents (FVs) employed to equalize hydrostatic pressure on walls of enclosures subject to rising or falling flood waters. Certain models also allow natural ventilation.

3.0 DESCRIPTION

3.1 General:

When subjected to rising water, the Smart Vent® FVs internal floats are activated, then pivot open to allow flow in either direction to equalize water level and hydrostatic pressure from one side of the foundation to the other. The FV pivoting door is normally held in the closed position by a buoyant release device. When subjected to rising water, the buoyant release device causes the unit to unlatch,

allowing the door to rotate out of the way and allow flow. The water level stabilizes, equalizing the lateral forces. Each unit is fabricated from stainless steel. Smart Vent® Automatic Foundation Flood Vents are available in various models and sizes as described in Table 1. The SmartVENT® Stacking Model #1540-511 and FloodVENT® Stacking Model #1540-521 units each contain two vertically arranged openings per unit.

3.2 Engineered Opening:

The FVs comply with the design principle noted in Section 2.7.2.2 and Section 2.7.3 of ASCE/SEI 24-14 [Section 2.6.2.2 of ASCE/SEI 24-05 (2012, 2009, 2006 IBC and IRC)] for a maximum rate of rise and fall of 5.0 feet per hour (0.423 mm/s). In order to comply with the engineered opening requirement of ASCE/SEI 24, Smart Vent FVs must be installed in accordance with Section 4.0.

3.3 Ventilation:

The SmartVENT® Model #1540-510 and SmartVENT® Overhead Door Model #1540-514 both have screen covers with \$^1/4-inch-by-\$^1/4-inch\$ (6.35 by 6.35 mm) openings, yielding 51 square inches (32 903 mm²) of net free area to supply natural ventilation. The SmartVENT® Stacking Model #1540-511 consists of two Model #1540-510 units in one assembly, and provides 102 square inches (65 806 mm²) of net free area to supply natural ventilation. Other FVs recognized in this report do not offer natural ventilation.

4.0 DESIGN AND INSTALLATION

SmartVENT® and FloodVENT® are designed to be installed into walls or overhead doors of existing or new construction from the exterior side. Installation of the vents must be in accordance with the manufacturer's instructions, the applicable code and this report. Installation clips allow mounting in masonry and concrete walls of any thickness. In order to comply with the engineered opening design principle noted in Section 2.7.2.2 and 2.7.3 of ASCE/SEI 24-14 [Section 2.6.2.2 of ASCE/SEI 24-05 (2012, 2009, 2006 IBC and IRC)], the Smart Vent® FVs must be installed as follows:

- With a minimum of two openings on different sides of each enclosed area.
- With a minimum of one FV for every 200 square feet (18.6 m²) of enclosed area, except that the SmartVENT® Stacking Model #1540-511 and FloodVENT® Stacking Model #1540-521 must be installed with a minimum of one FV for every 400 square feet (37.2 m²) of enclosed area.



- Below the base flood elevation.
- With the bottom of the FV located a maximum of 12 inches (305.4 mm) above the higher of the final grade or floor and finished exterior grade immediately under each opening.

5.0 CONDITIONS OF USE

The Smart Vent[®] FVs described in this report comply with, or are suitable alternatives to what is specified in, those codes listed in Section 1.0 of this report, subject to the following conditions:

5.1 The Smart Vent® FVs must be installed in accordance with this report, the applicable code and the manufacturer's installation instructions. In the event of a conflict, the instructions in this report govern. 5.2 The Smart Vent[®] FVs must not be used in the place of "breakaway walls" in coastal high hazard areas, but are permitted for use in conjunction with breakaway walls in other areas.

6.0 EVIDENCE SUBMITTED

Data in accordance with the ICC-ES Acceptance Criteria for Mechanically Operated Flood Vents (AC364), dated August 2015.

7.0 IDENTIFICATION

The Smart VENT® models recognized in this report must be identified by a label bearing the manufacturer's name (Smartvent Products, Inc.), the model number, and the evaluation report number (ESR-2074).

TABLE 1-MODEL SIZES

MODEL NAME	MODEL NUMBER	MODEL SIZE (in.)	COVERAGE (sq. ft.)
FloodVENT®	1540-520	15 ³ / ₄ " X 7 ³ / ₄ "	200
SmartVENT [®]	1540-510	15 ³ / ₄ " X 7 ³ / ₄ "	200
FloodVENT® Overhead Door	1540-524	15 ³ / ₄ " X 7 ³ / ₄ "	200
SmartVENT® Overhead Door	1540-514	15 ³ / ₄ " X 7 ³ / ₄ "	200
Wood Wall FloodVENT®	1540-570	14" X 8 ³ / ₄ "	200
Wood Wall FloodVENT® Overhead Door	1540-574	14" X 8 ³ / ₄ "	200
SmartVENT® Stacker	1540-511	16" X 16"	400
FloodVent® Stacker	1540-521	16" X 16"	400

For SI: 1 inch = 25.4 mm; 1 square foot = m²